


## Power plant connection

The power plants can be connected to the grid in two ways:



When configuring the power plant, select

- **in**: serial (**i**nternal) with grid power sensor
- **ex**: parallel (**e**xternal) with grid power sensor

The power plants are configured as internal by default.

## PV inverter

Obtaining relevant data from photovoltaic is possible by two ways:

1. adding power-sensor to measure produced electricity by PV (no connection to interver) - on how to add power sensor please see [Power Sensor](#)
2. connecting PV inverter by Modbus TCP to EVSE (only for SolarEdge inverters)

## SolarEdge inverter over Modbus TCP

### EVSE and PV inverter connection



To setup Modbus TCP on Inverter using SetApp:

- Select Site Communication menu
  - RS485-1 → Protocol → SunSpec (Non-SE Logger)
  - RS485-1 → Device ID, and enter the number 1.
  - Select Modbus TCP and set to Enable.
  - To modify the \*TCP port, select Port, set the port number to 502.

\*TCP port is 1502 by default.

From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
[http://wiki.hiq-universe.com/doku.php?id=en:robotina\\_charger:commissioning:pv\\_inverter&rev=1670593595](http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning:pv_inverter&rev=1670593595)

Last update: **2022/12/09 13:46**

