

Robotina Charger wiring

Network
Default connection to the LAN network:
<input type="checkbox"/>
Default connection via LTE 4G modem:
NOTE: All connected devices will have internet access via LTE modem which can result in high costs on your LTE account.
<input type="checkbox"/>
Optional LTE 4G modem connection:
<input type="checkbox"/>
Wireless power sensors
wireless connection of single phase power-sensor pm1-e-d to charger by wireless modbus-to-modbus bridge wm-1
<input type="checkbox"/>

wireless connection of single phase power-sensor with CT [pm1-e-d-ct](#) to charger by wireless modbus-to-modbus bridge [wm-1](#)



wireless connection of 3-phase power-sensor [pm3-e-d](#) to charger by wireless modbus-to-modbus bridge [wm-1](#)



wireless connection of 3-phase power-sensor with CT [pm3-e-d-ct](#) to charger by wireless modbus-to-modbus bridge [wm-1](#)



charger as modbus master wireless connected to modbus slave devices by wireless modbus-to-modbus bridge [wm-1](#) **Note:**supported modbus devices are power sensors defined in [hardware](#)



Charger and wireless power sensors.
One or more [WM-1](#) modules can be used. One or more power sensors can be connected to one [WM-1](#).



From:
<http://wiki.hiq-universe.com/> -

Permanent link:
http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:wiring&rev=1669988462

Last update: **2022/12/02 13:41**

