


# Configurator


## Overview

<b>1</b>	<b>Page navigation</b>
Overview page	
Access code management page	
Settings page	
UI settings page	
Events overview page	
<b>2</b>	<b>Entry procedure steps status</b>
<a href="#">count_status</a>	
<a href="#">disinfect_status</a>	
<a href="#">temperature_status</a>	
<a href="#">code_status</a>	
<a href="#">confirmation_status</a>	
<a href="#">entry_status</a>	
<b>3</b>	<b>schematics</b>
<b>4</b>	<b>Occupation counts</b>
Occupation count, click to correct the actual number of visitors.	
Occupation limits L1 / L2	
<b>5</b>	<b>Command buttons</b>
Gates Auto / Manual mode toggle	
Alarm reset button	
Confirmation button	



## Access Code management


<b>1</b>	<b>Edited code</b>
Click to enter the code you want to edit.	
<b>2</b>	<b>Code type</b>
Click to select edited code type. Options are L1 (level 1), L2 (level 2) or UL (unlimited).	
<b>3</b>	<b>Access point limits</b>
Click to enter count limits for each access point.	
<b>4</b>	<b>Code activation date</b>
Set code activation date and time. Set all to 0 for the code that is active immediately.	
<b>8</b>	<b>Code expiration date</b>
Set code expiration date and time. Set all to 0 for a code that has no validity limit.	
<b>6</b>	<b>Edit code commands</b>
[ search ] = Find settings for "edit code".	
[ save ] = Saves the code being edited with all settings.	
[ clear ] = Clear all edit settings.	



<b>1</b>	<b>Edited code</b>
[ delete ] = Delete edit code from the list.	
<b>7</b>	<b>Codes list</b>
List of access codes on the controller. Clicking on the code picks up all the code values in the edit fields above.	

## Settings

<b>1</b>	<b>Entry conditions</b>
Count limits: set count limits for L1 and L2; 0=not limited	
Disinfection: select if hand disinfection is required	
Thermal scan: select if body temperature scan is required s	
Reader: select if code reader is required	
Confirmation: select if confirmation is required	
<b>2</b>	<b>Entry detection settings</b>
Entry detection type: select entry detection type	
Entry time-out: max time between consecutive steps	
Confirmation time-out: max time allowed for confirmation	
Block time-out: time for hi temperature or wrong code alert	
After all time-outs entry procedure restarts.	
<b>3</b>	<b>Code reader settings</b>
Access point ID: ID for built in access point. Used when S Gate is part of bigger Access control system	
Thermal scan timeout: set the time for which the system remembers the temperature scan for the code user	
Access master code: set the code for local codes management	
Send LAN code query: set to enable sending code queries to other access controllers on LAN	
Process LAN code query: set to process queries from other controllers on LAN	
<b>4</b>	<b>Auxiliary input settings</b>
AUX input type: set auxiliary input function to presence sensor or to call button	
Presence / Call time-out: aux function timeout	
<b>5</b>	<b>Gates settings</b>
Entry gate time-out: set entry gate signal timeout, 0=no entry gate	
Exit gate time-out: set exit gate signal timeout, 0=no exit gate	
<b>6</b>	<b>Alarm settings</b>
Alarm duration: alarm active duration time	
Alarm beeper enabled: set to enable continuous beep during alarm	
Reset alarm on exit: set to reset alarm when exit is detected	
<b>7</b>	<b>Hardware overview</b>
Control system overview	
Select [ Autodetect ] to find S Gate controller in LAN (when red Xes are displayed)	
<b>8</b>	<b>Wireless devices management</b>
[ ]wireless management: set to enable management of wireless devices	



<b>1</b>	<b>Entry conditions</b>
first icon: wireless device paired status (x=none, ✓=paired)	
second icon: displaying wireless signal strength	
third icon: wireless device operating as repeater (click to enable).	
[- ]: delete wireless device	
[+ ]: add wireless device	
<b>9</b>	<b>Controller date and time settings</b>
set S Gate controller date and time.	
<b>10</b>	<b>Parameters management</b>
[init parameters ]: initialize all parameters to factory default values	
[save parameters ]: save all parameters to permanent memory	
[read parameters ]: read all parameters from permanent memory	


## User interfaces settings

<b>1</b>	<b>LED display texts settings</b>
Click to set the texts displayed on the LED display. Edit text alignment with spaces.	
<b>1</b>	<b>GUI display texts settings</b>
Click to set the texts that appear on the graphical user interface. The text will be centered automatically.	



## Events overview

<b>1</b>	<b>Events list</b>
The last 20 event codes and data are displayed. Event #00 happened last.	
<b>2</b>	<b>Events legend</b>
Legend for event code and data.	



From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
<http://wiki.hiq-universe.com/doku.php?id=en:sg3:configurator&rev=1606475169>

Last update: **2020/11/27 11:06**

