

# Commissioning

Strictly follow [Safety instructions](#)!

## Mounting

Mount Robotina charger (EVSE), PM1-E-D & PM3-E-D power sensors as well as wireless modbus WM-1 & relay WR-1 to a suitable place. For more details, please read here [Hardware](#).

## Wiring

Connect EVSE to the home LAN. Wire WM-1 module with power sensor and WR-1 relay with device.

## Configuration

Install and run [Robotina Charger](#) on your PC.

Go to the “**settings**” page.

With the “**autodetect**” button, the application will locate the controller in the local network.

Enter **names**, select **icons** for all sources and consumers.

From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
[http://wiki.hiq-universe.com/doku.php?id=en:robotina\\_charger:commissioning&rev=1670576429](http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning&rev=1670576429)

Last update: **2022/12/09 09:00**

