

HEMS HW Selection table

HEMS sets

Name	Code	Description	Contains
HEMS 1P set	HEMS-1P-D-02	HEMS, single phase power sensor and current transformer included	MC-230 PM1-E-D-CT CT1-E-50
HEMS 3P set	HEMS-3P-D-02	HEMS, three phase power sensor included	MC-230 PM3-I-D

HEMS devices

Name	Code	Description	Mounting
Home Linker	HL	Home linker, connecting Home to HIQ Universe	DIN rail, 6M
HEMS G2 controller	MC-230	HEMS controller, up to 6 energy sources and 4 managed consumers	DIN rail, 6M
Three-phase power-sensor	PM3-I-D	3-phase power sensor, direct connection	DIN rail, 3M
Single-phase power-sensor	PM1-E-D	1-phase power sensor, direct connection	DIN rail, 1M
Single-phase power-sensor	PM1-E-D-CT	1-phase power sensor, current transformer	DIN rail, 1M
Current transformer	CT1-E-50	Split core current transformer 50A	
Temperature sensor	ES	Digital temperature sensor	

From:
<https://wiki.hiq-universe.com/> -

Permanent link:
<https://wiki.hiq-universe.com/doku.php?id=en:hems:hardware&rev=1562827512>

Last update: **2019/07/11 06:45**

