

HEMS HW Selection table

HEMS sets

| Name | Code | Description | Contains |
|---------------------|---------------------|---|--|
| HEMS 1P Enocean set | HEMS-1P-D-01 | HEMS, single phase power sensor, current transformer and Enocean included | MC-230-01 |
| | | | PM1-E-D-CT |
| | | | CT1-E-50 |
| HEMS 3P Enocean set | HEMS-3P-D-01 | HEMS, three phase power sensor and Enocean included | MC-230-01 PM3-I-D |
| HEMS 1P set | HEMS-1P-D-02 | HEMS, single phase power sensor and current transformer included | MC-230-02 |
| | | | PM1-E-D-CT |
| | | | CT1-E-50 |
| HEMS 3P set | HEMS-3P-D-02 | HEMS, three phase power sensor included | MC-230-02 PM3-I-D |

HEMS devices

| Name | Code | Description | Mounting |
|---------------------------|----------------------------|--|--------------|
| Home Linker | HL | Home linker, connecting Home to HIQ Universe | DIN rail, 6M |
| HEMS G2 controller | MC-230-01 | HEMS controller, up to 6 energy sources and 4 managed consumers, Enocean | DIN rail, 6M |
| | MC-230-02 | HEMS controller, up to 6 energy sources and 4 managed consumers | DIN rail, 6M |
| Three-phase power-sensor | PM3-I-D | 3-phase power sensor, direct connection | DIN rail, 3M |
| Single-phase power-sensor | PM1-E-D | 1-phase power sensor, direct connection | DIN rail, 1M |
| Single-phase power-sensor | PM1-E-D-CT | 1-phase power sensor, current transformer | DIN rail, 1M |
| Current transformer | CT1-E-50 | Split core current transformer 50A | |
| Temperature sensor | ES | Digital temperature sensor | |

From:
<http://wiki.hiq-universe.com/> -

Permanent link:
<http://wiki.hiq-universe.com/doku.php?id=en:hems:hardware&rev=1563880655>

Last update: **2019/07/23 11:17**

