


# HEMS v1.2.0 wiring

## MC-230


Wiring of default configuration.

NOTE: several different configurations can be configured with [HEMS Configurator](#).




### Network → MC-230, IOT-L2-2 and optionally 4G modem

Default connection to the LAN:





Default connection via 4G modem:




Optional connection to the LAN:


NOTE: optional connection has to be configured on the cloud service. Please contact [support](#). The same applies to specific network requirements, i.e. static IP.






### PM1-E-D









From: <https://wiki.hiq-universe.com/> -

Permanent link: [https://wiki.hiq-universe.com/doku.php?id=en:hems\\_v1\\_2\\_0:methods\\_resources:wiring&rev=1632149468](https://wiki.hiq-universe.com/doku.php?id=en:hems_v1_2_0:methods_resources:wiring&rev=1632149468)

Last update: 2021/09/20 14:51

