


# HIQ UNIVERSE - Service provider

Accounts with access level of service provider have additional fields available:

- Instance manager
- Data API account manager
- Fleet manager


## Side menu



Side menu is activated by clicking menu icon (three horizontal lines at top-left). Menu items are dynamically created so they can be different for each service provider:

- **Home page** → section with all your subscribed HIQ Universe devices and services
- **TOOLS** → section with general site tools
  - Profile
  - Instance manager → ["Overview of installed systems"](#)
  - Reports → Subscription to reports (Depending on the installation).
  - Data API account manager → ["API key management"](#)
  - Fleet manager → ["Aggregation and overview of service providers installed systems"](#)
  - Sign out

## Overview of installed systems



The screenshot shows the 'Instances (961)' page in the HIQ Universe Instance Manager. The interface includes a search bar, a filter dropdown set to 'HIQ Universe', and a table of installed systems. The table has columns for Title, Type, Users, and Status. The systems listed include various types like HEMS(IoT), Dynamic D3, Flex, Smart Grid, and GOFLEX realm aggregate, each with associated user counts and status indicators (green checkmarks for online, red exclamation marks for offline).

Title	Type	Users	Status
HEMS(IoT)	HEMS(IoT)	0 0 0	✓
HEMS(IoT)	HEMS(IoT)	0 0 0	✓
HEMS(IoT)	HEMS(IoT)	0 0 0	✓
HEMS(IoT)	HEMS(IoT)	0 0 0	✓
Dynamic D3	Dynamic D3	0 0 1	!
Dynamic D3	Dynamic D3	0 0 1	!
Dynamic D3	Dynamic D3	0 0 0	!
Flex	Flex	1 0 0	✓
Flex	Flex	1 0 0	✓
Flex	Flex	1 0 0	✓
Dynamic D3	Dynamic D3	1 0 0	✓
Flex	Flex	1 0 0	✓
HEMS	HEMS	0 0 0	!
Smart Grid	Smart Grid	0 0 1	✓
Flex	Flex	1 0 0	✓
Flex	Flex	1 0 0	✓
Dynamic	Dynamic	1 0 0	✓
HEMS	HEMS	0 0 0	!
Smart Grid	Smart Grid	0 0 1	✓
Flex	Flex	0 0 0	!
HEMS	HEMS	0 0 0	!
Smart Grid	Smart Grid	1 0 0	✓
GOFLEX realm aggregate	GOFLEX realm aggregate	0 0 0	✓
GOFLEX realm aggregate	GOFLEX realm aggregate	0 0 0	✓

Table shows all installed systems by the service provider and their additional info:

- Name
- Type
- Users (nr. of Owners and Guests)
- Status (Online/Offline)

Clicking on the instance name will take you to instance home page as seen by end users. Clicking on the plus sign displays additional instance info:

- **Basic details**
- **User's details**

The screenshot shows the 'Basic details' tab of the HIQ Universe Instance Manager. The interface includes a navigation bar with 'Basic details' and 'Users' details' tabs. Below the tabs are 'Edit' and 'Delete' buttons. The main content area is divided into four sections: 'Basic information', 'Connections', 'Instance parameters', and 'Instance controllers'.

**Basic information**

Identification	[Bar chart]
Realm	[Bar chart]
Time zone	[Bar chart]
Ping time	[Bar chart]
Created	Sep 30, 2020 11:40:25 AM CEST
Modified	Oct 10, 2020 01:32:54 PM CEST
Last accessed	Oct 10, 2020 12:30:29 AM CEST

**Connections**

This instance does not have any connection.

**Instance parameters**

user_menu	[Bar chart]
IoT Linker serial number	[Bar chart]
Scripts Enabled	false
HEMS version	HEMS2
location_name	time_on_site
location_latitude	?
location_longitude	?
Description	
Maximum daily power (kW)	5
Maximum daily energy (kWh)	40
Maximum monthly energy (kWh)	500
Maximum production or consumption (W)	1000
Currency	EUR
Maximum daily value (EUR)	3
Maximum monthly value (EUR)	15
Maximum price (EUR)	1
icon	hems_ikona
Type label	HEMS
orig_var	1

**Instance controllers**

Controller name	Ping time
[Icon]	Error

Basic details displays information about the system. Here you can find:

- Basic info
- Connections
- Instance parameters
- Instance controllers

Parameters can also be changed with a click on Edit button.

The screenshot shows the 'Instances (1)' page in the HIQ Universe Instance Manager. The instance 'robotina' is listed with a status of 'HEMS(IoT)' and 1 user. The 'Users' tab is selected, showing the 'Owners' section with one user and the 'Guests' section with no guests. The footer contains contact information for Robotina and a note about the software being powered by SMIP v. 2.24.r2.

Title	Type	Users	Status
robotina	HEMS(IoT)	1	0

**Owners**

Owner email address	Remove
[redacted]	[Remove]

**Guests**

Guest email address	Share content	Share reports	Allow write to device	Remove
There are no guests on this instance.				

Number of records to display: 25

Robotina  
OIC - Hrpeleje 38  
SI-6420 Kozina  
Slovenia  
+386(0)5 689 2020  
info@robotina.com  
www.robotina.com  
Company Support Wiki

Powered by: SMIP v. 2.24.r2, CyBroSciServer Credits: Famfamfam Silk Icons, Fugue Icons

User's details shows all user that have access to this instance. Owners can be added or removed and have overview, control and settings over this instance. Guest account can be added or removed and will have an overview of an instance. We can select if we want to share reports with guests and to allow writing to the device. Guests can not change the settings.

## API key management

The screenshot shows the 'Data API account manager' page in the HIQ Universe. It displays 'No Data API account' with a 'Create account' button. The footer contains contact information for Robotina and a note about the software being powered by SMIP v. 2.24.r2.


Robotina  
HIQ Universe

Data API account manager

No Data API account [Create account]

Robotina  
OIC - Hrpeleje 38  
SI-6420 Kozina  
Slovenia  
+386(0)5 689 2020  
info@robotina.com  
www.robotina.com  
Company Support Wiki

Powered by: SMIP v. 2.24.r2, CyBroSciServer Credits: Famfamfam Silk Icons, Fugue Icons



An application programming interface key (API key) is a unique identifier used for calling program with an API.

Clicking on Create account will create a new Data API key that can be renewed or deleted.

## Aggregation and overview of service providers installed systems

Instance	SN	Is online	Online status changed	Linker online (last day in seconds)	Last reboot	Linker SW ver	Types version	Init Phase	CPU Temperature	MEM Available	Unpublished messages	at	MC	Last MC online	Prog MC	Documentation	DB Status
	34400+240	1	2021-04-07 06:41:28	86249	2021-04-06 12:14:51	10.31	1.5	4	68	475	0	2021-04-07 13:35:25	30529	2021-04-07 13:40:25	11.3	["VANILLA":"0005","log4j":"updated"]	0
	34400+242	0	2021-04-01 07:25:48	0	2021-03-30 12:49:11	10.31	1.5	4	58	511	0	2021-04-01 07:19:32	30525	2021-04-01 07:24:32	-1-1-1	["VANILLA":"0003","SYSUP-0007":"2020-06-05","SYSUP-0015":"2020-06-05","SYSUP-0016":"2020-06-05"]	0
	34400+250	0	2021-04-06 12:14:26	44054	2021-04-01 09:10:08	10.31	1.5	4	62	469	0	2021-04-06 12:10:37	30528	2021-04-06 12:10:37	-1-1-1	["VANILLA":"0003","SYSUP-0007":"2020-06-05","SYSUP-0015":"2020-06-05","SYSUP-0016":"2020-06-05"]	0
	34400+252	1	2021-04-07 05:50:36	86400	2021-03-09 17:04:17	10.41	1.5	4	59	383	0	2021-04-07 13:34:41	30549	2021-04-07 13:39:41	11.3	["VANILLA":"0003","SYSUP-0007":"2020-06-05","SYSUP-0015":"2020-06-05","SYSUP-0016":"2020-06-05"]	0
	34400+256	1	2021-04-07 11:38:06	86245	2021-04-06 12:15:57	10.36	1.5	4	59	533	0	2021-04-07 13:36:27	30546	2021-04-07 13:41:27	11.3	["VANILLA":"0003","SYSUP-0007":"2020-06-05","SYSUP-0015":"2020-06-05","SYSUP-0016":"2020-06-05"]	0

Aggregation and overview or so called fleet is a section where all relevant data from installed systems is collected and displayed. This section can vary amongst providers as the interface can be modified to suit the needs of individual service provider.

From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
[http://wiki.hiq-universe.com/doku.php?id=en:hems\\_v1\\_2\\_0:universe\\_service\\_provider&rev=1637330916](http://wiki.hiq-universe.com/doku.php?id=en:hems_v1_2_0:universe_service_provider&rev=1637330916)

Last update: **2021/11/19 14:08**

