


# Card reader

## Wiegand RFID receiver



Model number:	<b>CR-TR-W-IQ</b>	EM, 125 kHz, white
	<b>CR-TR-B-IQ</b>	EM, 125 kHz, black
	<b>CR-TR-S-IQ</b>	EM, 125 kHz, silver
	<b>CR-TR-I-IQ</b>	EM, 125 kHz, ivory
	<b>CR-TM-W-IQ</b>	Mifare, white
	<b>CR-TM-B-IQ</b>	Mifare, black
	<b>CR-TM-S-IQ</b>	Mifare, silver
	<b>CR-TM-I-IQ</b>	Mifare, ivory
Mounting:	Field, 2M rectangular flush box	
Connection:	Wiegand to <a href="#">Card reader interface</a>	

## Technical specifications

Power supply:	12 VDC
Protection:	IP66
Reading Distance:	3 cm
Card interface:	EM 125 kHz, Mifare
Output Interface:	Wiegand 26

From:

<http://wiki.hiq-universe.com/> -

Permanent link:

[http://wiki.hiq-universe.com/doku.php?id=en:hiq\\_hw:cr-hx&rev=1568287222](http://wiki.hiq-universe.com/doku.php?id=en:hiq_hw:cr-hx&rev=1568287222)

Last update: **2019/09/12 11:20**

