

# Push button

1 way			Polar white	<b>SM11PW</b>
			Soft black	<b>SM11SB</b>
			Elox silver	<b>SM11ES</b>
			Ivory	<b>SM11IW</b>
1 way with indicator			Polar white	<b>SM11PWIN</b>
			Soft black	<b>SM11SBIN</b>
			Elox silver	<b>SM11ESIN</b>
			Ivory	<b>SM11IWIN</b>
up / down			Polar white	<b>SM11PWNT10</b>
			Soft black	<b>SM11SBNT10</b>
			Elox silver	<b>SM11ESNT10</b>
			Ivory	<b>SM11IWNT10</b>

From:  
<https://wiki.hiq-universe.com/> -

Permanent link:  
[https://wiki.hiq-universe.com/doku.php?id=en:hiq\\_hw:tem-buttons](https://wiki.hiq-universe.com/doku.php?id=en:hiq_hw:tem-buttons)

Last update: **2019/07/25 11:56**

