# Wireless Modbus-to-Modbus bridge

#### Wireless Modbus-to-Modbus bridge




	Model number:	WM-1		
	Frequency:	ISM 868MHz (EU)		
	Dimensions:	93x45x27 mm		

### **Applications**

 Replacement for RS485 wiring solution with wireless. Optimal for long range Modbus RTU serial communications with half duplex configuration.

### Installation

- Carefully open WM-1 module and configure serial communication with jumpers. (Default configuration is 9600bps, 8N1 with normal timeout)
- Place WM-1 module at least 10cm from other objects. Installation is not recommended inside metal cabinets.
- Connect RS485 terminals to WM-1 RS485 terminals
  - A A
  - ∘ B B
  - ∘ C GND
- Connect to 230V power supply
- · Configure radio pairing



http://wiki.hiq-universe.com/ Printed on 2025/08/27 14:53

### **Features**


- replacement for RS485 wiring
- Modbus RTU serial protocol
- wired/wireless combinations
- very long range, no hopping
- protected private connection
- multiple slaves per device
- multiple addressable groups

# **Technical specification**

Power supply:	230V, 50/60Hz, 1W		
Ingress protection:	IP20		
Operating temperature:	-2050°C		
Storage temperature:	-4085°C		
Relative humidity:	085% n/c		

# **Terminals and wiring**


To power senso		Α	
	sensor	В	RS485 bus
		С	
To power	supply	L N	230V AC



### **Radio configuration**

#### Create new secure group

- \* turn on all devices as the same time
- \* within 10 seconds, while RF LED is blinking, press and hold button on one of the devices
- \* after a second, the new address is randomly generated and sent to all devices. RF LED will blink 3 times to confirm the new address.



From:

http://wiki.hiq-universe.com/ -

Permanent link:

http://wiki.hiq-universe.com/doku.php?id=en:hiq\_hw:wm-1&rev=1634737254

Last update: 2021/10/20 13:40

