






Confirmation status

	Confirmation disabled Permission from the receptionist or security guard is not required.
	Confirmation idle Permission is required but not active yet. Waiting for other entry conditions to be met.
	Confirmation pending Waiting for entry confirmation.
	Confirmation L1 and L2 Confirmed entry for all users.
	Confirmation only L2 Confirmed entry for L2 users.

From:
<https://wiki.hiq-universe.com/> -

Permanent link:
https://wiki.hiq-universe.com/doku.php?id=en:sg3:configurator:confirmation_status

Last update: **2020/11/27 11:21**

