HIQ-HC FW upgrade

Download and save CyPro IDE		CyPro
Run and install it		
Download and open project		hc-iq_v127.cyp
Find Home Controller NAD (sticker on top of HC)		☒
Select Home Controller	Hardware Setup [F5]... → Autodetect	☒
Send Program	Program → Send [F9]	☒
Start PLC program	Program → Start PLC [F11]	☒

HIQ-DC FW upgrade

Download and unzip CybroIEXManager		CyBrolexManager
Download and unzip Device Controller FWs		firmware.zip
Start CybroIEXManager.exe		☒
Scan for Home controller	[Scan]	☒
Select Home Controller		☒
Scan for connected IEX Device Controllers	[Scan IEX]	
For each connected device type open HIQ-DC FW	[Open]	☒
Send Firmware to HIQ-DC	[Send]	☒

From:
https://wiki.hiq-universe.com/ -

Permanent link:
https://wiki.hiq-universe.com/doku.php?id=partners:firmware&rev=1487770764

Last update: **2017/02/22 13:39**