

## Power sensor management

Default address on all power sensor is 149.  
Available addresses for sensors are listed in table.

| Address     | Power sensor position |
|-------------|-----------------------|
| 150         | Grid                  |
| 154,155,156 | PV                    |
| 157,158     | Battery storage       |
| 161..167    | Consumer              |

**Add** power sensor procedure:

- wire it to communication bus,
- only for PM1-E-D: press and hold the push-button on the power sensor until it appears **-SEt-** on display,
- it should appear in configurator as new device, click on button **add** next to the source or consumer where sensor should be assigned,
- repeat procedure for next.

**Note 1:** adding of power sensor is supported one by one.

**Note 2:** For PM3-E-D is possible to set address manually according to table, before adding it to communication bus.

**Del** power sensor procedure:

- make sure “new device” is empty,
- only for PM1-E-D: press and hold the push-button on the power sensor until it appears **-SEt-** on display,
- press **“del”** button next to the sensor,
- after a few seconds, the sensor should appear as the “new device”,
- sensor can be physically removed or it can be assigned to another device.

### Without grid power sensor

- **Virtual grid PS** is an option if no grid meter is used. Power, current and energy will be calculated from other power sensors.

From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
[http://wiki.hiq-universe.com/doku.php?id=en:robotina\\_charger:commissioning:power\\_sensor&rev=1671092963](http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning:power_sensor&rev=1671092963)

Last update: **2022/12/15 08:29**

