

Robotina Charger wiring

| |
|--|
| Network |
| Default connection to the LAN network: |
| <input type="checkbox"/> |
| Default connection via LTE 4G modem: |
| NOTE: All connected devices will have internet access via LTE modem which can result in high costs on your LTE account. |
| <input type="checkbox"/> |






Optional LTE 4G modem connection:



Wireless power sensors

wireless connection of single phase power-sensor [pm1-e-d](#) to charger by wireless modbus-to-modbus bridge [wm-1](#)



| |
|--|
| wireless connection of single phase power-sensor with CT pm1-e-d-ct to charger by wireless modbus-to-modbus bridge wm-1 |
|  |
| wireless connection of 3-phase power-sensor pm3-e-d to charger by wireless modbus-to-modbus bridge wm-1 |
|  |
| wireless connection of 3-phase power-sensor with CT pm3-e-d-ct to charger by wireless modbus-to-modbus bridge wm-1 |
|  |
| charger as modbus master wireless connected to modbus slave devices by wireless modbus-to-modbus bridge wm-1 Note: supported modbus devices are power sensors defined in hardware |
|  |
| Charger and wireless power sensors. One or more WM-1 modules can be used. One or more power sensors can be connected to one WM-1 . |
|  |

From:
<http://wiki.hiq-universe.com/> -

Permanent link:
http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:wiring&rev=1669988396

Last update: **2022/12/02 13:39**

