

# Robotina Charger wiring

<b>Network</b>
----------------

Default connection to the LAN network:
--



Default connection via LTE 4G modem:
--------------------------------------

<b>NOTE:</b> All connected devices will have internet access via LTE modem which can result in high costs on your LTE account.
--








Optional LTE 4G modem connection:



**Wireless power sensors**

wireless connection of single phase power-sensor [pm1-e-d](#) to charger by wireless modbus-to-modbus bridge [wm-1](#)



wireless connection of single phase power-sensor with CT <a href="#">pm1-e-d-ct</a> to charger by wireless modbus-to-modbus bridge <a href="#">wm-1</a>

wireless connection of 3-phase power-sensor <a href="#">pm3-e-d</a> to charger by wireless modbus-to-modbus bridge <a href="#">wm-1</a>

wireless connection of 3-phase power-sensor with CT <a href="#">pm3-e-d-ct</a> to charger by wireless modbus-to-modbus bridge <a href="#">wm-1</a>

charger as modbus master wireless connected to modbus slave devices by wireless modbus-to-modbus bridge <a href="#">wm-1</a> <b>Note:</b> supported modbus devices are power sensors defined in <a href="#">hardware</a>

Charger and wireless power sensors. One or more <a href="#">WM-1</a> modules can be used. One or more power sensors can be connected to one <a href="#">WM-1</a> .


From:  
<http://wiki.hiq-universe.com/> -

Permanent link:  
[http://wiki.hiq-universe.com/doku.php?id=en:robotina\\_charger:wiring&rev=1669988396](http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:wiring&rev=1669988396)

Last update: **2022/12/02 13:39**

