

Robotina Charger wiring

| |
|--------------------------------------------------------------------------------------------------------------------------------|
| Network |
| Default connection to the LAN network: |
| <input type="checkbox"/> |
| Default connection via LTE 4G modem: |
| NOTE: All connected devices will have internet access via LTE modem which can result in high costs on your LTE account. |
| <input type="checkbox"/> |
| Optional LTE 4G modem connection: |
| <input type="checkbox"/> |
| Wireless power sensors |
| Single phase power-sensor PM1-E-D |
| <input type="checkbox"/> |

Single phase power-sensor with current transformer [PM1-E-D-CT](#)



3-phase power-sensor [PM3-E-D](#)



3-phase power-sensor with current transformer [PM3-E-D-CT](#)




Charger and wireless power sensors.

One or more [WM-1](#) modules can be used. One or more power sensors can be connected to one [WM-1](#).



Power-sensors orientation



From:
<http://wiki.hiq-universe.com/> -

Permanent link:
http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:wiring&rev=1670506998

Last update: 2022/12/08 13:43

