Power sensor management

Default address on all power sensor is 149.

Available addresses for sensors are listed in table.

	Address	Power sensor position
	149	Default
	150	Grid
	154,155,156	PV
	157,158	Battery storage
	161167	Consumer

Add power sensor procedure:

- wire it to communication bus,
- only for PM1-E-D: press and hold the push-button on the power sensor until it appears **-SEt-** on display,
- it should appear in configurator as new device, click on button **add** next to the source or consumer where sensor should be assigned,
- repeat procedure for next.

Note 1: adding of power sensor is supported one by one.

Note 2: PM3-E-D supports address setting manually on its display before adding it to communication bus.



Del power sensor procedure:

- make sure new device is empty,
- only for PM1-E-D: press and hold the push-button on the power sensor until it appears **-SEt-** on display,
- press del button next to the sensor,
- after a few seconds, the sensor should appear as the **new device** (as on image above),
- sensor can be physically removed or it can be assigned to another device.

Note: After del power sensor has default address 149.



Without grid power sensor

• **Virtual grid PS** is an option if no grid meter is used. Power, current and energy will be calculated from other power sensors.

Last update: 2022/12/15 en:robotina_charger:commissioning:power_sensor http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning:power_sensor&rev=1671094818 09:00

http://wiki.hiq-universe.com/ -

Permanent link:

http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning:power_sensor&rev=1671094818

Last update: 2022/12/15 09:00

