HIQ UNIVERSE

HIQ Universe is a cloud service that enables:

- An overview of current power consumption and
- An overview of the history of electrical power and energy consumption and production.

Access point: https://my.hiq-universe.com

HIQ Universe Log-in

HIQ Universe Smart spaces	x +		x
$\overleftarrow{\leftarrow}$ \rightarrow C $\widehat{\mathbf{u}}$	① ♣ https://my.hiq-universe.com/rs/sa/login/index ···· ♡ ☆ Q Search	🗊 🙂	≡
	<u>ä</u> -		
	Smart spaces		
	Username or email		
	Password		
	Stay signed in		
	Sign in		
	Forgot your password? Create new account		
	Terms, Privacy		

Log in with your username or email and password to see your HIQ Universe subscription dashboard.

To reset forgotten password click on "Forgot your password?"

To create new account click on "Create new account".

Create HIQ Universe account

HIQ Universe Create new ac	count X +				x
$\overleftarrow{\leftarrow}$ \rightarrow $\overleftarrow{\mathbf{C}}$	① 🔒 https://my.hiq-universe.com/rs/sa/register/index ত ☆	111	•	T	≡
	Create new account Choose your username Your first name and last name				
	Your first name and last name				
	Email address				н
	UTC+1:00 Africa/Algiers				
	•••••				
	Confirm your password				
	Nisem robot.				
	Accept Terms and Conditions				

In the appropriate fields, enter:

- Username
- First and Last name
- E-mail address
- Timezone
- Password

Click on "I'm not a robot"


Accept Terms and Conditions.

Click on Create account.

A confirmation link will be sent to your email address.

Proceed to "HIQ Universe Log-in" screen.

Reset forgotten password



In the appropriate field, enter email address.

Click on "I'm not a robot"

Click on "Reset password".


You will receive email with password reset link.

HIQ Universe Reset password X +				3
← → C û î ≜ https://my.hiq-u	niverse.com/rs/sa/resetpassword/inde	🚥 🗵 🏠 🔍 Search	III\ 🗊 👳 =	=
	Ö r			
	M			
	Reset password			
	New password			
	Repeat password			
	Save new password			
	Terms, Privacy			

Enter new password and click on "Save new password".


Proceed to "HIQ Universe Log-in" screen.

Add HEMS controller



Enter HiQ universe activation code that you received from your installer.

HIQ Universe subscription dashboard




You will see tiles for all your subscribed HIQ Universe devices and services.

Go to Main HEMS view by clicking on HEMS tile or

add new HEMS device by clicking on blank tile with + sign.

"User profile set-up" is invoked by clicking on user name on top right.


Main HEMS view



Main HEMS page consists of 3 sections:

- "Title and view selection row" at the top
- "Power flow chart" on left side
- "Power and energy time-plot" on right





Side menu is activated by clicking menu icon (tree vertical lines at top-left). Menu items are dynamic created so can be different for each user. Typical menu items from top:

- Language selection
- Home page \rightarrow section with all your subscribed HIQ Universe devices and services
 - MyHems → "Main HEMS view"
 - Settings → "HEMS settings"
- TOOLS \rightarrow section with general site tools
 - Profile \rightarrow "User profile set-up"
 - \circ Sign out → Log off from HIQ Universe

Title and view selection row

My HEMS	4	\otimes	Daily	Monthly	Yearly	۲	<	\rangle	2018/12/17	\sim	[↓]	Kozina	13:24
http://wiki.hig-unive	erse.co	n/									F	Printed on 202	25/07/06

- HEMS name
- Lighting icon \rightarrow time-plot displays energy or power
- Money icon \rightarrow time-plot displays currency
- Daily \rightarrow time-plot displays power
- Monthly \rightarrow time-plot displays energy per day
- Yearly \rightarrow time-plot displays energy par month
- Target icon \rightarrow time-plot go to now
- < \rightarrow time-plot goes to previous term
- > \rightarrow time-plot goes to next term
- Date \rightarrow Select term for time-plot
- Download icon \rightarrow Download "csv" data for displayed time-plot period
- Location of HEMS installation
- Time at HEMS installation site.

Power flow chart

power for 13:27


× (F

Displays actual power flow with:


- Power sources (Local PV, wind, co-generation plants) at top
- Grid (divided by tariffs) on left side
- Storage (battery) systems on right side and
- Consumers on bottom.

Unused items are soft greyed out with X. Items without actual power are displayed as dots.

Power and energy time-plot



power for 10:55



On bottom is time-plot for selected time period (in title row). By clicking on time plot a term for legend display is selected. Above there is power/energy legend.

User profile set-up

	HI	Q Unive	rse Profile	×	+								×
¢	_) →	G	ŵ	(i) 🔒	https://my.hiq-universe.com/rs/sa/user_profile/	Ē	⊌	☆	Q Search		lii\	Т	≡
			Robotina HIQ Univ	/erse	ពិ			ſ,		Goran	Kocjancic		-
	Ba	sic in	formation										
	Userr	name			isername								
	Creat	ted			1/05/2018 01:34:41 PM CET from IP 89.212.246.0	66							
	Previ	ous lo	gin		2/17/2018 12:31:16 PM CET from IP 89.212.246.6	6							
	Last l	login			2/17/2018 12:48:57 PM CET from IP 89.212.246.	66							
	Last p	passw	ord change		2/17/2018 12:45:50 PM CET from IP 89.212.246.	66							
	Pro	ofile											
	Main	realm			HEMS -								
	Full n	name			Goran Kocjancic								=
	Emai	laddr	ess		goran.kocjancic@gmail.com								
	Time	zone			UTC+1:00 Europe/Amsterdam 🔹								
		Sav	ve changes										
	For	reign	realms										
	Pas	sswo	rd										
	Old p	asswo	ord										
		passw											
	Repe	at pas	sword										
		Chan	ge password										

Basic information section:

- Username
- Created date and IP
- Previous and last login date and IP
- Last password change date and IP

Profile section:

- Main realm display
- Full name, email address and timezone edit fields

Foreign realms - devices and services where you have access to bat you are not owner.

Password: fields for password changing.

HEMS settings

HIQ Universe Settings	< +		-)	<u> </u>
← → ♂ ☆ ○ □	https://my.hiq-universe.com/rs/pp/918/iot_hems2_pro	••• 🗵 🏠 🔍 Search	lii\	🗊 🕇	: :	≡
HIQ Universe	ពិ	∫ Gora	n Kocjancic			-
Settings						
Device name Location	My HEMS					
Location name Location latitude	Kozina					
Location longitude						
Energy price						-
Low tariff price (€/kWh)	0.100					-
High tariff price (€/kWh)	0.200					
Feed-in tariff price (€/kWh)	0.100					
Timeplots range						
Electricity						
Max daily power (kW)	1					
Max daily energy (kWh)	1					
Max monthly energy (kWh)	20					
Cost						
Max daily value (€)	10					
Max monthly value (€)	100					
Save settings						
Share your device						
Owner	goran.kocjancic@gmail.com					
Guest account						
Guest email address Remo	ve quest				_	Ŧ

Sections:

- Settings:
 - Device name
 - $\circ\,$ Location name and coordinates
- Energy price: per tariff energy price
- Timeplots range: ranges for various timeplots
- Share your device: manage device sharing guest accounts

My Things and Smart-grid settings

My Things GUI could be accessed within the HiQ Universe platform by clicking the MyThings item within the main menu. Individual devices are presented as a group of cards, divided on four groups:

- Consumers
- Production
- Storage
- Sensors.

Consumers

Within the group Consumers, the first card present a general consumption of the object - a background consumption. The following items present real controllable devices, such as DHW Heater, Heat pump, wireless socket, etc. An example of a device is shown in the following image.

×

The form of a card of each consumer is composed of the general part, history and settings part.

General

General part contains:

- **name** of a device, which can be changed by user.
- icon (button) enables toggling the device operation state (Switch on / Switch off).
- state label contain the information of device operation state (On / Off / Error).
- **power** label contain the information of device consumption power in watts.

History

History part shows historical consumption of a device. The temporal range can be selected as daily, weekly, monthly or yearly. Daily and weekly range shows power consumption in watts, while monthly and yearly range shows energy consumption in kilowatt-hours.

The interface enables time-frame selection and time-frame alignment to current time.

Settings

• **Manual override** presents the time in minutes. When the user switches on the device, the device will automatically turn off after manual override minutes.

Example: manual override is set as 30 minutes. When the user switches on the device, it will

switch off after 30 minutes.

Note: Manual override is disabled if it is set to 0 minutes.

• If manual override is bigger than 0, the device will switch off automatically after specified number of minutes.

Smart grid settings

• Cloud optimization

Cloud optimization enables or disables smart grid service.

• Smart grid status

Smart grid status label shows smart grid operation state with the following states: * a

- b
- Idle the device is not in activation
- Executing the device is in activation
- Enabled
- Max duration in a day
- Max request in a day
- Suspend time

Production

Storage

Sensors

From: http://wiki.hiq-universe.com/ -

Permanent link: http://wiki.hiq-universe.com/doku.php?id=en:hems_nedo_idrija:universe&rev=1601032424



Last update: 2020/09/25 11:13