

# HIQ Hotel BMS

HIQ Hotel BMS WEB based application which can be hosted on our server and offered as SaaS (software as a service) or on your own server. As it is WEB application there is no need for installation of any additional software on workstation. HIQ Hotel BMS is fully customized to hotel specific needs and budget.

## Typical BMS

**Overview**

Room	Booked	Room pr.	Bath pr.	WLR	BND	Fire alert	Temperature
I	In 01 h	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 25.0 °C ai: 22.7 °C fi: 28.3 °C
							B: H 0 set: 20.0 °C ai: 24.4 °C fi: 22.1 °C
							S: OFF set: 19.0 °C ai: 25.7 °C
II	90	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 27.0 °C ai: 25.7 °C fi: 24.4 °C
							B: H 0 set: 22.0 °C ai: 27.5 °C fi: 25.4 °C
							S: OFF set: 12.0 °C ai: 29.9 °C
III	In 01 d	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 30.0 °C ai: 25.2 °C fi: 25.4 °C
							B: H 0 set: 19.0 °C ai: 29.3 °C fi: 24.0 °C
							S: OFF set: 12.0 °C ai: 29.9 °C
IV	In 04 m	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 25.0 °C ai: 25.8 °C fi: 22.4 °C
							B: H 0 set: 20.0 °C ai: 27.3 °C fi: 23.0 °C
							S: OFF set: 12.0 °C ai: 29.9 °C
V	90	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 25.5 °C ai: 24.8 °C fi: 23.8 °C
							B: H 0 set: 22.0 °C ai: 25.5 °C fi: 24.3 °C
							S: OFF set: 12.0 °C ai: 29.9 °C
S	-	[Icon]	-	-	-	[Icon]	R: C B set: 24.5 °C ai: 24.8 °C

Access

robotina  
SaaS - Cloud services

Access

Guest access codes:

	I	II	III	IV	V
22. 08.	2322			1435	5646
23. 08.	3214		7651	6232	
24. 08.	2244		1136	5426	3132
25. 08.					
26. 08.					
27. 08.					
28. 08.					
29. 08.					
30. 08.					
31. 08.					

create code  
delete code  
extend code  
clear selection

Room

Room state: Not locked, Presence

Time to next check in: 08:01 h 52 m

Room clean request

Do Not Disturb

Room presence

Bathroom presence

Service mode

Water heater: 44.4 °C - OFF

Refrigerator

Bathroom sockets

Room sockets

Tee kitchen sockets

Ventilation

Sensa: 25.7 °C - OFF

Jacuzzi: 32.2 °C - ON

RCB

Lights

Terrace main

Terrace entrance

Terrace LED stripe

Room main

Room standing

Reading left

Reading right

Room LED stripe

Fire alert

Smoke sensor: [reset]

Room ambient temperature abs.: 22.7 °C [reset]

Room ambient temperature rise: [reset]

Room floor temperature abs.: 28.3 °C [reset]

Room floor temperature rise: [reset]


Bath ambient temperature abs.: 24.4 °C [reset]

Bath ambient temperature rise: [reset]


Bath floor temperature abs.: 22.1 °C [reset]

Bath floor temperature rise: [reset]

HVAC



Settings



**Presence**



From: <http://wiki.hiq-universe.com/> -

Permanent link: [http://wiki.hiq-universe.com/doku.php?id=en:hotel:hiq\\_bms&rev=1566466367](http://wiki.hiq-universe.com/doku.php?id=en:hotel:hiq_bms&rev=1566466367)

Last update: 2019/08/22 09:32

