

# HIQ Hotel BMS

HIQ Hotel BMS WEB based application which can be hosted on our server and offered as SaaS (software as a service) or on your own server. As it is WEB application there is no need for installation of any additional software on workstation. HIQ Hotel BMS is fully customized to hotel specific needs and budget.

## Typical BMS

**Overview**

Room	Booked	Room pr.	Bath pr.	HLR	BND	Fire alert	Temperature
I	In 01 h	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 25.0 °C ai: 22.7 °C fi: 28.3 °C
							B: H 0 set: 20.0 °C ai: 24.4 °C fi: 22.1 °C
II	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	R: C B set: 27.0 °C ai: 25.7 °C fi: 24.4 °C
							B: H 0 set: 22.0 °C ai: 27.5 °C fi: 25.4 °C
III	In 01 d	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	S: OFF set: 12.0 °C ai: 29.9 °C
							R: C B set: 18.0 °C ai: 25.2 °C fi: 25.4 °C
IV	In 04 m	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	B: H 0 set: 18.0 °C ai: 29.3 °C fi: 24.6 °C
							R: C B set: 25.0 °C ai: 25.8 °C fi: 22.4 °C
V	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	[Icon]	B: H 0 set: 20.0 °C ai: 27.3 °C fi: 23.6 °C
							R: C B set: 25.5 °C ai: 24.8 °C fi: 23.8 °C
S	-	[Icon]	-	-	-	[Icon]	B: H 0 set: 22.0 °C ai: 25.5 °C fi: 24.3 °C
							R: C B set: 24.5 °C ai: 24.8 °C


Access

The screenshot shows the 'robotina' web interface for 'Access' management. The page title is 'Access' and it is part of the 'Hotel Theodoros' system. The main content area displays a table of 'Guest access codes' with columns for date, code, and room. The table contains several rows of data, including dates from 22.08 to 31.08 and codes like 2322, 2214, 2244, 2525, 2651, 1136, 1435, 4252, 5426, and 2132. To the right of the table are buttons for 'create code', 'delete code', 'extend code', and 'clear selection'. The left sidebar contains navigation menus for 'HIQ', 'Hotel Theodoros', and 'User menu'.


Room

The screenshot shows the 'Room' control page for 'Room 1'. The page displays various room status indicators and controls. The left sidebar contains navigation menus for 'HIQ', 'Hotel Theodoros', and 'User menu'. The main content area is divided into several sections: 'Room state' (Not locked, Presence), 'Time to next check in' (08:01 h 52 m), 'Room clean request', 'Do Not Disturb', 'Room presence', 'Bathroom presence', 'Service mode', 'Terrace main', 'Terrace entrance', 'Terrace LED stripe', 'Room main', 'Room standing', 'Reading left', 'Reading right', 'Room LED stripe', 'Water heater' (44.4 °C - OFF), 'Refrigerator', 'Bathroom sockets', 'Room sockets', 'Tee kitchen sockets', 'Ventilation', 'Seema', 'Jacuzzi' (25.7 °C - OFF), 'RCB' (22.2 °C - ON), 'Smoke sensor', 'Room ambient temperature abs.' (22.7 °C), 'Room ambient temperature rise', 'Room floor temperature abs.' (28.3 °C), 'Room floor temperature rise', 'Bath ambient temperature abs.' (24.4 °C), 'Bath ambient temperature rise', 'Bath floor temperature abs.' (22.1 °C), and 'Bath floor temperature rise'.

HVAC



Settings



**Presence**



From: <https://wiki.hiq-universe.com/> -

Permanent link: [https://wiki.hiq-universe.com/doku.php?id=en:hotel:hiq\\_bms&rev=1566466367](https://wiki.hiq-universe.com/doku.php?id=en:hotel:hiq_bms&rev=1566466367)

Last update: **2019/08/22 09:32**

