

Commissioning

Strictly follow [Safety instructions!](#)

Mounting

Mount Robotina charger (EVSE), [PM1-E-D](#) & [PM3-E-D](#) power sensor as well as [WM-1](#) & [WR-1](#) to a suitable place. For more details, please read [Hardware](#).

Wiring

Connect EVSE to the home LAN. Wire WM-1 module with power sensor and WR-1 relay with device (e.g. heat pump, el. radiator).

Configuration

Install and run [Robotina Charger](#) on your PC. With the “**autodetect**” button, the application will locate EVSE in the local network. Enter **names**, select **icons** for all sources and consumers.

1. How to add or delete power sensor please see [Power Sensor](#)
2. How to set PV SolarEdge inverter please see [PV Inverter](#)
3. How to set WM-1 and WR-1 please see [Wireless WR1 & WM1](#)
4. How to set heat pump please see [Heat Pump](#)

From:
<http://wiki.hiq-universe.com/> -

Permanent link:
http://wiki.hiq-universe.com/doku.php?id=en:robotina_charger:commissioning&rev=1671026384

Last update: **2022/12/14 13:59**

