

# Typical installations

## Small shop, pharmacy

### Requirements

- limited number of visitors
- one passage for access and exit
- automatic door
- required temperature measurement
- required disinfection

### Installation

- SGate is installed at the entrance from the outside of the automatic door.
- Entry detection sensors are mounted on one of the sides or on an additional carrier depending on the physical layout of the SGate relative to the door..
- The automatic door opening signal is connected to the SGate and in parallel to the internal automatic opening sensor.
- The staff has a wireless button to confirm alarms or to open the door manually in case of exceptions.



### Settings



## Department store

### Requirements


- limited number of visitors
- one-way entrance with swing gate
- separate exit
- required temperature measurement
- required disinfection
- staff can access it by scanning the code even when the count limit 1 is exceeded
- staff do not need to scan the temperature 4 hours after a successful scan
- hand disinfection is not mandatory for employees

## Installation


- SGate is installed at the entrance from the outside of the swing gate.
- Entry detection sensor is mounted on side of SGate or on an additional carrier depending on the physical layout of the SGate relative to the gate.
- Security guard has a wireless button to confirm alarms or to open the door manually in case of exceptions.



## Settings



## Staff code




## Offices

### Requirements


- number of visitors not limited
- one passage for access and exit
- automatic door
- required temperature measurement
- employees do not need to scan the temperature 4 hours after a successful scan
- required disinfection
- required authentication with code for employees and guests
- guests are exceptionally allowed to enter with confirmation of the reception (without code)

### Installation

- SGate is installed at the entrance from the outside of the automatic door.
- Entry detection sensor is mounted on side of SGate or on an additional carrier depending on the physical layout of the SGate relative to the door.
- Receptionist has a wireless button or PC application to confirm alarms or to open the door manually in case of exceptions.
- Upon booking a meeting, each guest receives a QR code, which is time limited.



## Settings



## Employee code

SG3-MT Configurator v1.0.1

Edit code: #00: 0009508038 Type: 1: L1

Access point ID:

0	1	2	3	4	5	6	7	8	9
-0	255	000	000	000	000	000	000	000	000
-1	000	000	000	000	000	000	000	000	000
-2	000	000	000	000	000	000	000	000	000
-3	000	000	000	000	000	000	000	000	000
-4	000	000	000	000	000	000	000	000	000
-5	000	000	000	000	000	000	000	000	000
-6	000	000	000	000	000	000	000	000	000
-7	000	000	000	000	000	000	000	000	000
-8	000	000	000	000	000	000	000	000	000
-9	000	000	000	000	000	000	000	000	000

Code list:

```
#00: T1 0009508038 #20: T0 0000000000 #40: T0 0000000000 #60: T0 0000000000 #80: T0 0000000000
#01: T2 0009963026 #21: T0 0000000000 #41: T0 0000000000 #61: T0 0000000000 #81: T0 0000000000
#02: T0 0000000000 #22: T0 0000000000 #42: T0 0000000000 #62: T0 0000000000 #82: T0 0000000000
#03: T0 0000000000 #23: T0 0000000000 #43: T0 0000000000 #63: T0 0000000000 #83: T0 0000000000
#04: T0 0000000000 #24: T0 0000000000 #44: T0 0000000000 #64: T0 0000000000 #84: T0 0000000000
#05: T0 0000000000 #25: T0 0000000000 #45: T0 0000000000 #65: T0 0000000000 #85: T0 0000000000
#06: T0 0000000000 #26: T0 0000000000 #46: T0 0000000000 #66: T0 0000000000 #86: T0 0000000000
#07: T0 0000000000 #27: T0 0000000000 #47: T0 0000000000 #67: T0 0000000000 #87: T0 0000000000
#08: T0 0000000000 #28: T0 0000000000 #48: T0 0000000000 #68: T0 0000000000 #88: T0 0000000000
#09: T0 0000000000 #29: T0 0000000000 #49: T0 0000000000 #69: T0 0000000000 #89: T0 0000000000
#10: T0 0000000000 #30: T0 0000000000 #50: T0 0000000000 #70: T0 0000000000 #90: T0 0000000000
#11: T0 0000000000 #31: T0 0000000000 #51: T0 0000000000 #71: T0 0000000000 #91: T0 0000000000
#12: T0 0000000000 #32: T0 0000000000 #52: T0 0000000000 #72: T0 0000000000 #92: T0 0000000000
#13: T0 0000000000 #33: T0 0000000000 #53: T0 0000000000 #73: T0 0000000000 #93: T0 0000000000
#14: T0 0000000000 #34: T0 0000000000 #54: T0 0000000000 #74: T0 0000000000 #94: T0 0000000000
#15: T0 0000000000 #35: T0 0000000000 #55: T0 0000000000 #75: T0 0000000000 #95: T0 0000000000
#16: T0 0000000000 #36: T0 0000000000 #56: T0 0000000000 #76: T0 0000000000 #96: T0 0000000000
#17: T0 0000000000 #37: T0 0000000000 #57: T0 0000000000 #77: T0 0000000000 #97: T0 0000000000
#18: T0 0000000000 #38: T0 0000000000 #58: T0 0000000000 #78: T0 0000000000 #98: T0 0000000000
#19: T0 0000000000 #39: T0 0000000000 #59: T0 0000000000 #79: T0 0000000000 #99: T0 0000000000
```

Active on: 00.00.00 00:00 [now] [clr]

Expire on: 00.00.00 00:00 [now] [clr]

search save clear delete

SGATE

robotina 19.11.2020 13:37

## Guest code

SG3-MT Configurator v1.0.1

Edit code: #00: 0009963026 Type: 2: L2

Access point ID:

0	1	2	3	4	5	6	7	8	9
-0	005	000	000	000	000	000	000	000	000
-1	000	000	000	000	000	000	000	000	000
-2	000	000	000	000	000	000	000	000	000
-3	000	000	000	000	000	000	000	000	000
-4	000	000	000	000	000	000	000	000	000
-5	000	000	000	000	000	000	000	000	000
-6	000	000	000	000	000	000	000	000	000
-7	000	000	000	000	000	000	000	000	000
-8	000	000	000	000	000	000	000	000	000
-9	000	000	000	000	000	000	000	000	000

Code list:

```
#00: T2 0009963026 #20: T0 0000000000 #40: T0 0000000000 #60: T0 0000000000 #80: T0 0000000000
#01: T0 0000000000 #21: T0 0000000000 #41: T0 0000000000 #61: T0 0000000000 #81: T0 0000000000
#02: T0 0000000000 #22: T0 0000000000 #42: T0 0000000000 #62: T0 0000000000 #82: T0 0000000000
#03: T0 0000000000 #23: T0 0000000000 #43: T0 0000000000 #63: T0 0000000000 #83: T0 0000000000
#04: T0 0000000000 #24: T0 0000000000 #44: T0 0000000000 #64: T0 0000000000 #84: T0 0000000000
#05: T0 0000000000 #25: T0 0000000000 #45: T0 0000000000 #65: T0 0000000000 #85: T0 0000000000
#06: T0 0000000000 #26: T0 0000000000 #46: T0 0000000000 #66: T0 0000000000 #86: T0 0000000000
#07: T0 0000000000 #27: T0 0000000000 #47: T0 0000000000 #67: T0 0000000000 #87: T0 0000000000
#08: T0 0000000000 #28: T0 0000000000 #48: T0 0000000000 #68: T0 0000000000 #88: T0 0000000000
#09: T0 0000000000 #29: T0 0000000000 #49: T0 0000000000 #69: T0 0000000000 #89: T0 0000000000
#10: T0 0000000000 #30: T0 0000000000 #50: T0 0000000000 #70: T0 0000000000 #90: T0 0000000000
#11: T0 0000000000 #31: T0 0000000000 #51: T0 0000000000 #71: T0 0000000000 #91: T0 0000000000
#12: T0 0000000000 #32: T0 0000000000 #52: T0 0000000000 #72: T0 0000000000 #92: T0 0000000000
#13: T0 0000000000 #33: T0 0000000000 #53: T0 0000000000 #73: T0 0000000000 #93: T0 0000000000
#14: T0 0000000000 #34: T0 0000000000 #54: T0 0000000000 #74: T0 0000000000 #94: T0 0000000000
#15: T0 0000000000 #35: T0 0000000000 #55: T0 0000000000 #75: T0 0000000000 #95: T0 0000000000
#16: T0 0000000000 #36: T0 0000000000 #56: T0 0000000000 #76: T0 0000000000 #96: T0 0000000000
#17: T0 0000000000 #37: T0 0000000000 #57: T0 0000000000 #77: T0 0000000000 #97: T0 0000000000
#18: T0 0000000000 #38: T0 0000000000 #58: T0 0000000000 #78: T0 0000000000 #98: T0 0000000000
#19: T0 0000000000 #39: T0 0000000000 #59: T0 0000000000 #79: T0 0000000000 #99: T0 0000000000
```

Active on: 19.11.20 14:00 [now] [clr]

Expire on: 19.11.20 16:00 [now] [clr]

search save clear delete

SGATE

robotina 19.11.2020 13:44


## Health Center

## Requirements


- visitors can enter only at a specified time
- one passage for access and exit
- automatic door
- required temperature measurement
- required disinfection

## Installation


- SGate is installed at the entrance from the outside of the automatic door.
- Entry detection sensors are mounted on side of SGate or on an additional carrier depending on the physical layout of the SGate relative to the door.
- Receptionist has a wireless button to confirm alarms or to open the door manually in case of exceptions.
- Upon booking, each visitor receives a QR code, which is time limited.



## Settings



## Guest code



From:  
<http://wiki.hiq-universe.com/> -



Permanent link:  
<http://wiki.hiq-universe.com/doku.php?id=en:sg3:installations&rev=1606474948>

Last update: **2020/11/27 11:02**